


# **KMG**

## **K.N. CROWDER**

### **MFG. INC.**

[www.kncrowder.com](http://www.kncrowder.com)

## **Door Bottom Shoes**



**CT-55**

## **Installation Instructions**

- 1. Measure and cut door shoe to fit.**
- 2. Position seal on door with gasket compressed 1/16" against sill.**
- 3. Mark screw holes.**
- 4. Drill pilot holes for screws using a 7/64" (#36) drill bit.**
- 5. Install with screws provided.**
- 6. Adjust position so that gasket does not impede proper closing and latching of door.**

10/09