


KMG

K.N. CROWDER

MFG. INC.

www.kncrowder.com

Door Bottom Shoes



CT-747



CT-748

Installation Instructions

1. Measure and cut door shoe to fit.
2. Position seal on door with gasket compressed 1/16" against sill.
3. Mark screw holes.
4. Drill pilot holes for screws using a 7/64" (#36) drill bit.
5. Install with screws provided.
6. Adjust position so that gasket does not impede proper closing and latching of door.



UL10C Positive Pressure Tested Gasketing Material for Fire Doors. Also Classified in accordance with UBC 7-2 (1997).



UL10B Gasketing Material for Fire Doors

Intended for Application to Classified Steel fire doors rated up to 3 hours and Wood type fire doors up to 1-1/2 hours.

Smoke and Draft Control gasketing (Category H) meets requirements of UBC 7-2 (1997) part 2, NFPA 105, IBC and UL1784. Intended for application to 'S' label doors.

10/09