

Installation Instructions

Step #1:
Once jamb is prepped for strike, loosely fasten Back Plate to jamb using two (2) #8-32 x 1-1/4" Pancake Combo Screws.

Step #2:
Insert Dust Box.

Step #3:
Loosely fasten Test Plate using two (2) M4 x 6mm Phillips Head Machine Screws through top and bottom holes.

Step #4:
Make minor adjustments accordingly. Back Plate shifts horizontally ①, and Dust Box shifts vertically ②.

Step #5:
Once position is finalized, tightly fasten screws through Back Plate and unfasten Test Plate screws to remove Test Plate.

Step #6:
Fasten Face Plate using two (2) M4 x 6mm Screws. Adjust Dust Box and tightly fasten.

