


C-94BL Barn Lock Series

Handing Identification Sheet

How to Determine Barn Door Handing


1. Start on outside of opening.
2. On what side of the opening is the barn door installed?
3. In what direction does the door slide open?



RH-Inside

1. Standing outside
2. Door on Inside
3. Opens to right


Use Left-Hand
C-94BL



RH-Outside

1. Standing outside
2. Door is outside
3. Opens to right


Use Right-Hand
C-94BL



LH-Inside

1. Standing outside
2. Door on inside
3. Opens to left

Use Right-Hand
C-94BL



LH-Outside

1. Standing outside
2. Door is outside
3. Opens to left

Use Left-Hand
C-94BL