





C-2025 and C-2035



Installation Instructions



- Side mount hanger
- Cycle tested up to 150,000 times
- Top mount double (bypass) track
- For 3/4 in [19.1 mm] or 1 3/8 in [34.9 mm] doors
- For up to 60 lbs [27 kg] doors

Parts List




Complete C-2025 kit illustrated. Cut-outs in track to expose components.

Optional Products








Elevation View




Product Details and Dimensions

Section View



Typical installation location for floor guides

For bypassing applications




Installation Steps

Step #1:

Determine door size, header height, track position and bottom clearance based on the kit code ordered by using dimensions shown in detail views on previous page.

Step #2:

Cut C-2025/C-2035 aluminum track to size if required, typically 2x door width. Locate and pre-drill $\text{Ø}3/16$ in holes through center of track. Secure track to structural support/header with #10 x 3/4" Pan Head Screws [FT3], quantity of 16 are supplied.




Note: Solid support is required and spacing is recommended to be between 12-16 in [300-400 mm] on center. Consult structural engineer to ensure adequate support and fastening.

Step #3:

Determine which hangers will be used on each track.

For 3/4 in [19.1 mm] doors, C-2025 3/8" Offset Hangers on rear door, C-2025 5/8" Offset Hangers on front door.

For 1 3/8 in [34.9 mm] doors, C-2025 5/8" Offset Hangers on rear door, C-2025 3/8" Offset Hangers on front door.




Step #4:

If using hollow core doors, avoid trimming door at top end in order to have an adequate amount of solid material to receive hanger screws.

Step #5:


Mount hangers on back of door 2 1/2 in [63.5 mm] from each edge or 3 in [76.2 mm] to centre of hanger. Secure using oblong holes with #10 x 3/4" Pan Head Screws [FT3] and #10 External Tooth Lock Washer [FT10], 2 per hanger.

Note: With hangers seated against top edge of door, locate screws near top of oblong holes to permit maximum adjustment. Do not tighten to allow for adjustment.




Step #6:

Position C-1205 Nylon Guide Set per typical installation location details and secure to floor with three (3) #8 x 3/4" Pan Head Screws [FT2].





Step #7:

Front door must be installed before rear door. Lift door under front track channel and engage by angling the top of door towards back.



Step #8:

Adjust door height and plumb. Tighten screws to secure adjustments. Use one (1) #8 x 3/4" Pan Head Screws [FT2] in circular holes on each hanger to lock final adjustment.



Step #9:

Repeat steps #7 - 8 for rear door.

