


C-94BL-HLDP Handicap Lockset & Pulls

Barrier-Free (ADA Compliant)

Installation Instructions

For 1 3/4 in [44.5 mm] thick doors only




The ADA Standard 404.2.3 is from the Dept. of Justice ADA Publication of Sept 15, 2010. K.N. Crowder Mfg. Inc. encourages the end user to double check all state and federal standards for your particular project.


**The total opening has to be 8 in [203.2 mm] minimum greater than the federal "clear width" dimension of 36 in [914.4 mm] to work properly.

***The bottom of the C-90DP pulls must be installed 34 in [863.6 mm] from the finished floor. This will give 48 in [1219.2 mm] from the finished floor to the top of the C-90HL handle, thus meeting Code 404.2.7.


Components Included:




C-94BL
Barn Door Lock Body




C-90DP
Back to Back Handle Pulls



C-90HL
Handle Lever




C-90HER
Occupancy Indicator ER Coin Turn




Note: Door size = opening width plus 6 in [152.4 mm]
Example: 40 in [1016 mm] opening + 6 in [152.4 mm] = 46 in [1168.4 mm] wide door

Door Prep Template

Not to scale Inside of Door



Outside of Door



Expose Screws
Rotate thumb turn 90 degrees to project bolt and expose the two bolt screws



Remove Bolt from Lock Body
Extend the bolt and loosen screws without removing them and remove bolt assembly from the lock



Insert Lock into Door
Insert lock into door
Loosen insert mounting screws



Reattach Bolt
Slightly rotate loose thumb turn to make lock body screws visible
Reinstall bolt assembly by aligning screw holes
Tighten screws
Use thumb turn to fit bolt assembly back in




Install Armour Front
Secure lock in door by tightening screws into door
Install armour front onto basefront




Mount Cuff
Mount the bolt cuff aligning per template
Install trim accordingly

Strike Kit

Supplied Standard



Not to scale



Number of drywall shims used is a function of drywall thickness.
Number of strike shims used is a function of the gap between the face of the door and the wall.

