


# CGC-914/CGC-201 Series


KNC

## Guide System


Installation Instructions




### Parts' List



**C-913 Floor Guide (1)**




**#10 x 1-1/2" Flat Head Screws (2)**  
[FT7]




**CGC-914-IC Guide x length (1)**  
length = door width


### Disassembled Parts List



**CGH Aluminum Guide Body with C-914 Guide Channel x length (1)**



**CGH-IC Rubber Boot x length (1)**



**CGH-F Fascia x length (2)**




**CGH-GB Glass Bolt**




**CGH-FEC Full End Cap (2)**




**CGH Nylon Spacers**




**3/8-16 Hex Jam Nut**  
[FT20]




**#6-32 x 1/2" Flat Phillips Undercut Machine Screw for CGH-F (8)**




### Parts' List



**C-200 Floor Guide (1)**




**#8 x 3/4" Pan Head Screws (2)**  
[FT2]




**CGC-201-IC Guide x length (1)**  
length = door width


### Disassembled Parts List



**CGH Aluminum Guide Body with C-201 Guide Channel x length (1)**




**CGH-IC Rubber Boot x length (1)**



**CGH-F Fascia x Length (2)**




**CGH-GB Glass Bolt**




**CGH-FEC Full End Cap (2)**



**CGH Nylon Spacers**




**3/8-16 Hex Jam Nut**  
[FT20]




**#6-32 x 1/2" Flat Phillips Undercut Machine Screw for CGH-F (8)**

# Product Details and Dimensions

## Elevation View




## Section View




## Typical installation location for guides

For pocket door applications





For barn door applications



# Installation Steps



## Step #1:

Prepare glass door with holes per prep template on glass hanger instructions. Insert CGH Nylon Spacers in prep holes of glass door. Slip CGH-[] Rubber Boot over bottom edge of glass, then CGH Aluminum Guide Body over rubber boot. Align holes on rubber boot and hanger body with CGH Nylon Spacers and holes on glass door. See below.



## Step #2:


Thread CGH-GB Glass Bolt through holes in glass and secure with 3/8-16 Hex Jam Nuts [FT20]. See below.



## For CGC-914

### Step #3:


Position C-913 Guide per typical installation location details on page 2 and secure to floor with (2) #10 x 1-1/2" Flat Head Screws [FT7]



## For CGC-201



### Step #3:

Position C-200 Guide per typical installation location details on page 2 and secure to floor with (2) #8 x 3/4" Pan Head Screws [FT2].




## Step #4:

Raise door, position over guide, and under hangers in track. Refer to hanger instructions for door adjustments.



**Step #5:**

Snap CGH-F Fascia onto guide body, one per side. Place end caps onto ends of each guide and fasten with (4) #6-32 x 1/2" Flat Phillips Undercut Machine Screw [FT49].

**Step# 6:**

Resume track and hardware installation.